



Preparation for installation:

Please use the adjustment screws to adjust the adjustable wishbones to the same length.

Lubricate all the places where the wishbone will work - with copper grease.

It is best to initially - at the time of installation - set them to the same length as the standard wishbone on the car.

Control arm installation:

To replace the control arm, the car must be lifted on a lift.

For convenience, the wheel can be removed for replacement.

Unscrew the bolts securing the stock control arm with wrenches. If necessary, detach additional elements such as cables, sensors, etc.

Pull out the bolts securing the stock control arm and remove it from the place where it was mounted.

The adjustable control arm must be inserted in place of the stock control arm, remembering to install the factory bolts, washers and nuts that were previously removed.

The exception is a situation in which the adjustable control arm is equipped with these elements.

If the control arm is equipped with elements that serve to secure against unscrewing, they should now be screwed until the elements tighten the thread on the adjustment element (M6 Allen screw and M6 self-locking nut - the tools are an Allen key and a 10 wrench).

After installing the wishbone, lower the car to the ground and then tighten the bolts securing the wishbone to the car components from the repair pit - according to the torque specified by the manufacturer of the given car. After the installation is complete, go to a workshop that deals with suspension geometry to set the wheel geometry using professional equipment.

Safety:

- Installation should be done by a professional (car mechanic, workshop).
- No modifications may be made to the product.
- The wishbone ends may not be unscrewed beyond the safe range.
- Periodically inspect the wishbone and all mounting screws and securing screws (if any).

This product is an aftermarket accessory and not designed by the vehicles manufacturer for use on this vehicle. As such, Buyer assumes all risk of any damage caused to the vehicle or person during faulty installation or use of this product. Installation by proffessional highly recommended.